



ELISE™ 2

THE POWERFUL
DUAL-MOTORED
VIBRATOR

PRODUCT DESCRIPTION

With dual motors of supreme power and a deeply fulfilling length, this iconic LELO targets your pleasure centers for the most intense, deep-reaching, body-shaking sensations you'll ever experience.

- **Dual motors for 2 times the intensity**
Powerful motors in the base and tip offer surging sensations to the clitoris and g-spot for the most unforgettable orgasms
- **Contoured for a naturally fulfilling feeling**
Featuring a long, sleek and thick design for satisfying depth and body-shaking stimulation
- **Intuitive interface for perfect control**
Total command over all the sensations at the touch of a button, allowing you to change power and mode freely

SPECIFICATIONS

- **Materials:** ABS Plastic / Silicone
- **Finish:** Matte
- **Size:** 220 x 42 x 36mm / 8.7 x 1.7 x 1.4in.
- **Diameter:** ø 39mm / 1.5in.
- **Insertable Length:** 130mm / 5.1in.
- **Weight:** 170g / 6.0oz.
- **Battery:** Li-Ion 920mAh 3.7V
- **Charging:** 2hrs at 5.0V 500mA
- **User Time:** Up to 4hrs
- **Standby:** Up to 90 days
- **Frequency:** 120Hz
- **Max Noise Level:** <50dB
- **Interface:** Variable interface dial, 5 modes.

FEATURES

Fuller, deeper stimulation from two powerful motors in base and tip

Smooth body-safe silicone design

Easy-to-use controls to explore 8 vibration patterns



LELO

L 220mm/8.66"

Ø 42mm/1.65"

CONTROLS



- Press + to turn on and to increase vibration strength.
- Press - to lower vibration strength; hold - to turn off.
- Press ▲ and ▼ to cycle through the different vibration patterns.
- Lock by holding + and - for 5 seconds; the light will turn off when the device is locked.
- Unlock by pressing for 5 more seconds; the light will turn on when the device is active.

CHARGING

Always charge LELO massagers before first use and only use original chargers provided by LELO



The light will pulsate to indicate that your massager is charging

Insert the LELO charger into the charging socket

When fully charged, the light will emit a steady glow

LELO

HYGIENE & CARE



Use **LELO's Antibacterial Cleaning Spray** before and after each use for total peace of mind.

When cleaning with water, **ALWAYS** use a premium antibacterial solution

100% Waterproof and Rechargeable Design

Store your LELO massager in its protective storage pouch between uses.

WARNING: Do not boil or use metal scour. Avoid leaving your LELO in direct sunlight and **NEVER** expose it to extreme heat. Do not use on swollen or damaged skin. Keep your LELO out of the reach of children.

IMPORTANT: For Adult Use Only. Those who may be pregnant, have a pacemaker, diabetes, phlebitis or thrombosis should consult with a medical professional regarding the risk of blood clots before using any personal massage product.



LELO

WARRANTY REGISTRATION

1. Visit **LELO.com** and click **REGISTER/LOG IN** in the top right corner of the screen.
2. Follow the directions to register your product and attach details of your purchase.

Don't forget to take advantage of
LELO's full warranty coverage.



The serial number is on the back of the authenticity card provided with every LELO product.

LELO

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems).

The crossed-out dustbin symbol indicates that this product should not be treated as household waste, but rather be brought to the appropriate collection point for recycling of electrical and electronic equipment.



* FCC Mark, C-Tick and IC certifications relevant to remote-controlled products only.

Disclaimer: Users of this LELO Product do so at their own risk. Neither LELO nor its retailers assume any responsibility or liability for the use of this product. Further, LELO reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

Applicable for ALL products. Model may be changed for improvements without notice.

© 2015 LELo AB. ALL RIGHTS RESERVED.

LELo AB, Birger Jarlsgatan 22, 114 34 STOCKHOLM, SWEDEN.

LELo Inc., 4320 STEVENS CREEK BLVD., SUITE #205, SAN JOSE, CA 95129, USA.

DESIGNED AND DEVELOPED BY LELO SWEDEN

MANUFACTURED BY LELO IN CHINA

WEBSITE WWW.LELO.COM - SUPPORT CUSTOMERCARE@LELO.COM

LELO

LELO